

4D ULTRATEK BLACK DIGIT GUIDE

**CHOOSE THE CORRECT DIGIT FOR
THE REG AND BEGIN TO LINE UP**

**REMOVE THE 3M ADHESIVE
PROTECTIVE COVER**

**CHECK ALIGNMENT IS ACCURATE
BEFORE PRESSING DOWN**

**PRESS DOWN FIRMLY TO BOND
THE DIGIT TO THE PLATE**

**REMOVE THE TOP
PROTECTIVE COVER**

**MOVE ON TO THE NEXT DIGIT
AND REPEAT THE STEPS**

**For more information on UltraTek
please call our Sales Admin team**

0121 623 8050 or visit hillsnumberplates.com